

BMW E46 LED Angel Eyes Installation

1. Check contents and testing rings with them connected to power source making sure they are all in working order.



2. Remove front headlight lenses and indicators, for instruction please refer to:

<https://www.ssdd-motorsport.com/content/FittingInstructions/CCFLDIYGUIDE%20E46.pdf>

3. Route the wires through the opening after you've remove the original sidelight bulb holder:



4. Use the supplied clips to fix the rings into position:



5. Another photo showing routing of wires to the back of headlight:



6. When both rings are on and wires routed to the back, test them again to make sure the connections are working.

7. Refit the plastic shroud and front lenses etc and make sure you keep the original sidelight bulb in the holder. Find a secure place away from plastic or wires and cable tie them, usually this is behind the slam panel.

8. If you wish to use the remote fade function, you can push a wire through the driver side firewall and connect the wires into driver side footwell light positive cable, with one of the trigger wires.



Enjoy your lights!

*Product specifications might be revised from time to time. Photos for reference only.